

杰特光电设备有限公司 Jetlasers

PL-C Pro User Manual

Choosing the Battery for PL-C Pro

- 2x Cr123a/16340 Li-on Batteries : 405nm, 445nm
- 1x 18650 Li-on Batteries : 532nm, 635nm, 650nm, 808nm, 830nm, 980nm, 1064nm
- ★ Instruction: Load the negative end “-” first. ★

Press the Power Switch

- Press the *Power Switch* on the Tailcap
- ★ When the *power switch* is pressed, the laser function is enabled.

PowerSwitch the Laser On/Off

- Insert the key and turn it Clockwise to the Position of **Green** Spot.
- ★ The beam is on now.
- ★ To turn the laser off, turn the key Anti-Clockwise to the Position of **Red** Spot.
- ★ The user can also turn the laser off by pressing the power switch on the tailcap.

Adjust the focus (beam diameter, divergence, etc.)

- ★ Just like other portables by Jetlasers, this PL-D Pro series is also equipped with focus adjustable feature.

Recommended duty cycle ★

2mins on, 30s off ★

USER CAUTION!

- ★ **DO NOT USE AS A LASER POINTER!**
- ★ **NEVER AIM AT AIRCRAFT OR STARS!**
- ★ **DO NOT GET DIRECT BEAM IN EYE!**
- ★ **DO NOT GET REFLECTED BEAM IN EYE!**
- ★ **DO NOT LOOK OR STARE AT DIFFUSE REFLECTIONS!**
- ★ **DO NOT GET BEAM ON SKIN - BURN HAZARD!**
- ★ **ONLY FOR USE BY MATURE PERSONS UNDERSTANDING THE HAZARDS OF THIS LASER.**

